

## TECHNICAL DATA SHEET

Part#: 15A-GW

### Tweezers - 3 Star Cutting - 15A-GW Series - Carbon Steel

Designed for general purpose cutting of small wires or flashing. This tool is epoxy coated to prevent oxidation.

The 15A-GW 70° angulated tip cutting tweezer is ideal for general purpose cutting of soft wire up to 0.010". This tool is considered a tip cutter in that the blades meet most predominately at the tip. All of the force applied to the tweezer gets transferred to the tips.

• Precision Level	★★★
• Material	Carbon Steel
• Surface Resistivity	10 <sup>5</sup> -10 <sup>6</sup> ohms/sq
• Shape	Angulated
• Tip Size	.330" x .350" (8.3mm x 8.8mm)
• Tip Angle	70°
• Tip Length	.350" (8.8mm)
• Body Width	0.4" (10mm)
• Body Height	.10" (2.50mm)
• OAL	4.5" (112.5mm)
• Weight (OZ)	1.5
• UPC	662847003332
• Schedule B	8203.20.20.00
• ECCN	EAR99
• UNSPSC Code	27112105
• Country of Origin	Switzerland
• Group	Standard Head (15A-GW)

