

TECHNICAL DATA SHEET

Part#: 9247SL

Cutters - Medium Taper Relieved Head - Optimum Flush - Slim Line - Black Oxide Coated

Designed for cutting .032" soft wire leaving a small 'pinch' on the wire

The 9247SL optimum flush new and improved Lazer Line[®] medium SLIM LINE tapered/relieved head cutters feature BLACK OXIDE FINISH and a smaller frame with new molded grip. They are made of AISI 52100 carbon tool steel with induction hard cutting blades to RHC 63-65. The CNC machining allows the joint surfaces to be perfect to allow for long life. The dual leaf springs provide a smooth action. It features molded ergonomic antimicrobial Anti-Static grips (10¹⁰ ohms/sq surface resistivity).

• Precision Level	★★★★
• Material	Carbon
• Surface Resistivity	10 ¹⁰ ohms/sq
• Shape	Taper Relieved Head
• Type of Cut	Optimum Flush
• Cutting Capacity	.005 - .032"
• Blade Angle	16°
• Blade Length	.278" (6.95mm)
• Body Width	0.375" (9.38mm)
• Body Height	.225"
• OAL	4.5" (112.5mm)
• Weight (OZ)	3
• UPC	662847014086
• Schedule B	8203.20.60.60
• ECCN	EAR99
• UNSPSC Code	27111511
• Country of Origin	USA
• Group	Medium Head - 9200 Series

